




# IXCHEL

## QUICK START GUIDE




### Disable Lane Assist

- Turn engine ON > Using the center display...
- Tap  (upper left) > swipe left > tap Settings 
- Under Quick Access > tap  to toggle ON/OFF.

### POWER

- Touch display above sink to activate.
- Swipe to *System Overview* if not already there.
- Tap **AC MODE** to cycle thru Inverter modes.
- Leave OFF when not charging or using A/C.



### BATTERY CHARGING

- Turn A/C Mode to Inverter ON.
- Plug 30-amp extension cord into 30 amp outlet.
- If needed, use 30-to-15 amp adapter.



30 AMP EXTENSIONCORD

### SOLAR CHARGING

- Process is fully automated.

### ALTERNATOR CHARGING

- Process is fully automated.
- DO NOT charge battery by idling engine.



30-to-15 AMP ADAPTER

## WATER

- Fresh water fill port is outside at rear end of the passenger side. Fill from potable water sources.
- Power switch for pump is on countertop backsplash.  
| = ON   O = OFF
- Switch for dump valve is in cabinet above sink.  
LIGHT ON = OPEN

## VENTILATION

- Fan remote is on passenger side wall.
- Close rear windows & turn OFF Fan before driving.
- Close rear windows if any chance of rain.

## HEATER

- Heater control is on countertop backsplash.
- Press rotary dial center to activate, and cycle thru:  
1 = TEMP   2 = TIME   3 = ON (RED CIRCLE AROUND DIAL)
- If running heat on low, run for 10-20 minutes on high before shutting off.
- **Never run heater less than 10 minutes.**



## QUESTIONS?

Email [info@campncar.com](mailto:info@campncar.com)